



## Culvert example

Darren Lumbroso, HR Wallingford

Culverts are simple structures

Hydraulics are complex

Six principle types of flow:

- > Weir or orifice control at inlet
- > Four cases of control at or downstream of the outlet



Any questions?

HR Wallingford  
Howbery Park, Wallingford, Oxfordshire OX10 8BA, United Kingdom  
tel +44 (0)1491 835381 fax +44 (0)1491 832233 email [info@hrwallingford.com](mailto:info@hrwallingford.com)